



ELMDENE INTERNATIONAL LIMITED **3 KEEL CLOSE INTERCHANGE PARK** PORTSMOUTH HAMPSHIRE PO3 5QD, UK

Tel: +44 (0) 23 9269 6638 +44 (0) 23 9266 0483 Fax: Web: www.elmdene.co.uk

ELM-PA-G3-X Panic Button Guide

X is colour code: ELM-PA-G3-W White, ELM-PA-G3-B Brass, ELM-PA-G3-SS Steel ELM-PA-G3-BK Black

Panic alarm trigger device with two push buttons

Meets the requirements of PD6662: 2017 at Grade 3, Environmental Class II and EN 50131-1:2006.

A range of aesthetically pleasing two button panic alarm (PA) devices available with black. white, brass or stainless steel appearance covers. Suitable for commercial and domestic installation.

Features include:

- · Silent two button operation
- Compliant with PD6662: 2017, and the requirements of EN 50131-1:2006, Security grade 3. Environmental class II.
- Suitable for use under the ACPO "10 point plan" for false PA reduction
- Integral, selectable resistor values for easy FSL connection to most alarm control panels.
- · Alternative double pole wiring option
- Spare terminals for connection of multiple units
- · Key operated mechanical reset
- Selectable normally open or normally closed alarm contacts
- Cover and removal from wall tamper (normally closed)
- · Visual indication of ready or latched state

Specifications

Temperature Range Dimensions

-10°C to+40°C

Contact

Power Handling Voltage Rating Current Rating Resistance Operating Life

62 x 80 x 27mm

10VA 30Vdc 1.0A Max <300mohms >1 x 10° operations



Setting reed - Normally Open (N.O.) or Normally Closed (N.C.)

Default is set to Normally closed. Please skip this section if this is the required setting.



Normally Closed (Factory Default)

Normally

Open

- 1. Remove PCB by gently bending the two tabs back and pull the board up and out.
- 2. Remove the sliding mechanism (you may need to loosen the friction adjustment screw).
- 3. Push out magnet from other side and swap to desired position.

Follow steps 1&2 in reverse order to re-assemble. Take care not to damage the reed switch.



- 1. Press both buttons to move mechanism out of the way and gain access to the bottom fixing hole.
- 2. Mark positions of holes on the wall.
- 3. Drill holes to required depth and use appropriate wall plugs or fixings (No. 6 / 5mm).
- 4. Drive bottom countersunk screw through base and into wall.
- 5. Insert top pan head screw through PCB and plastic and screw into wall. Take care not to snap the PCB tamper breakout.
- 6. Use friction adjustment screw to ensure sliding mechanism does not move without being pushed by buttons or reset key. DO NOT OVERTIGHTEN
- 7. Angle lid as shown above. Slide upward before pushing lid closed. Fasten lid shut with screw.

Use of the PA button

- 1. Push both buttons together to operate. After use indicator will be red (latched).
- 2. To reset insert the key into the slot as shown.
- 3. Turn key clockwise as far as it will turn (about 120 degrees) to reset the PA.
- 4. Turn the key anticlockwise back to the start and remove it.
- 5. Indicator will now be yellow (ready).

Correct Use of PA Buttons

PA buttons should be installed in accordance with any applicable regulations relating to panic alarms. Potential users should be advised in the use of the PA

Wiring the PA Button

Gardtec

DSC

Bosch, Europlex

Connections to the PA button are made via the screw terminals numbered 1 to 6. Configuration of the resistor values to match the alarm panel is by link jumpers. See the table below to find the resistor values and series or parallel option needed.

Location of Configuration Parts



6k8

2k2

5k6

4k7

2k2

5k6

Series

Series

Series



For additional PAs, connect as "Other PAs"

Page 3